



UNIVERSAL OIL STOP LEAK

BENEFITS

- ✓ Allround additive, works in engine & gear oil, ATF, power steering fluid and hydraulic oils
- ✓ Stops and prevents oil leakages through seals like valves, crankshafts, dusts, oil filter O-rings, oil pans and all other plastic or rubber based seals
- ✓ Reduces oil consumption
- ✓ Makes seals swell back to original size and regain all-new pliability
- ✓ Eliminates the need for expensive repairs
- ✓ Prolongs the service life of the engine
- ✓ Improves engine performance by enhancing motor compression
- ✓ Prevents or reduces emission of blue exhaust smoke
- ✓ Reduces engine noise
- ✓ Reduces emission of hazardous exhaust gases
- ✓ Does not contain harmful solvents or solids

USAGE

Universal Oil Stop Leak can be used in all oils to stop leakage. Does not clog filters and is not harmful for catalytic converters. DO NOT ADD TO BRAKE FLUID.

DIRECTION

Determine total oil volume in the system to be treated. Add Universal Oil Stop Leak in a volume equal to 1% of the total. Add preferably to warm oil. Operate the system for 10 minutes.



OIL

Packaging details

Art. No.:	68113
Content:	50 ml
Packaging:	24x50 ml
Pallet:	100 cartons
Languages:	EN, DE

Technical specifications

Density g/cm ³ :	1,03
Colour:	Amber
Odour:	Characteristic

VISIT US:

